



Once installed if your abs light is not working correctly flip the switch on the side of the abs fix to the other position. This should correct the issue.

Tap the red wire from the ABS fix into the wire going to pin B9 with a T tap

Tap the black wire from the ABS fix into the wire going to pin B10 with a T tap.

Cut the ABS wire located at cluster C6 a couple inches back from the green connector, strip both ends back and crimp on the ¼ male spade on to the car side and the ¼ female spade to the C6 wire going to the cluster.

Connect the car side male spade to the female spade on the Blue wire from the abs fix and the C6 wire to the cluster female spade to male spade on the Gray wire from the ABS fix.

If your Brake light is not working correctly insert the back wire with pin into C3 and use the T tap to tap into B10. This grounds that pin and should correct the brake light issue.